Radiance

EDS Powerball



DIRECTIONS

This concentrated degreaser quickly penetrates and loosens grease, oil, ink, coffee, blood and other similar soils from washable surfaces. This mild pH product is safe on most surfaces not harmed by water. This water based product contains no fragrances, chlorinated solvents, petroleum solvents, phosphates or flammable ingredients.

DIRECTIONS

Dilution is preset at 1 oz. of product per gallon of cold tap water.

FLOORS AND GENERAL CLEANING: Mop, spray or wipe onto surface, and scrub if needed. Wipe or rinse clean.

CONCRETE AND BRICK: Allow to penetrate for 10 minutes. Agitate with a stiff bristle brush. Rinse clean.

FILTER CLEANING: Remove filter from unit, spray onto surface, allow to penetrate for 10 minutes, and rinse clean.

PRESSURE SPRAYER: Spray on and let soak for heavily soiled areas. Wipe or rinse clean.

FOR WASTE DISPOSAL USE: Dispose of any unused product in accordance with local, state and federal regulations. Rinse container thoroughly with water and recycle empty containers. Do not reuse containers.

The EDS dispenser is not a water pressure management system. Water should only be turned on during the use of the EDS dispenser. A shut-off valve should be within 6 ft. of where the dispenser is in use. Water supply pressure should be below 55 PSI. If pressure is higher, a pressure regulator should be installed to bring pressure down to 50 PSI.

APPLICATIONS

For cleaning / degreasing in:

- Manufacturing & warehousing
- Schools & offices
- Kitchens, hotels & service facilities

BENEFITS

- Concentrated
- Environmentally Responsible Choice
- Contains No Chlorinated or Petroleum Solvents

SPECIFICATIONS

Color	Green
Fragrance	None
pH Range	11.0 - 11.5
Dilution	
Density	8.42

PACKAGING

ITEM #	5	SIZ	Έ
101474192	/	3	Ī



